

ZoomerRoo

Battery Disconnect Switch Fitting Guide (fuse):

Three Simple Steps:

1. Remove the negative battery cable.
2. Attach the switch onto the negative battery post and connect the in-line fuse.
3. Attach the negative battery cable to the post end of the switch and connect the other end of the in-line fuse onto the negative battery cable.

To disconnect the battery turn the black wheel 1/4 turn anti clockwise. To connect the battery turn the wheel clockwise until tight. The black wheel can also be removed for added security. The in-line fuse provides a small amount of power that will keep the clock, radio, alarm going etc.... (15amp Glass Fuse).



More Great Products Available Online:
www.ZoomerRoo.co.uk